



HIDRACAR S.A.

ANTI-CORROSION VALVE



Prevents that, when a corrosive liquid is circulating through the circuit, and in case the separator element (bladder, membrane or bellows) of the dampener gets broken, the corrosive liquid could corrode the stainless steel gas charging valve and escape to the exterior.

This anti-corrosion valve is supplied together with the standard gas charging valve.

004-AI + PVDF



VÁLVULA ANTI-CORROSIÓN

Evita que, cuando por el circuito circula un líquido corrosivo, y en caso de rotura del elemento separador (vejiga, membrana o fuelle) del amortiguador, el líquido pueda corroer la válvula de carga de gas de acero inoxidable y fugar al exterior.

Esta válvula anti-corrosión se suministra conjuntamente con la válvula de carga de gas estándar.



HIDRACAR S.A.

Pol. Ind. Bufalvent - c/ Ramón Farguell, 71

08243 Manresa (Barcelona) - SPAIN

www.hidracar.com • E-mail: hidracar@hidracar.com

Tel.: +34 93 833 02 52 Fax: +34 93 833 19 50